

Your Entertainment. All-in-One



• •

low TV strives to provide customers with high-quality TV entertainment. We offer a wide variety of programs from vorld-renowned TV channels alongside customer-friendly value-added services - all delivered from a reliable service

With so much to choose from, we've made life easier, My Now, Watchlist, TV Guide, Personalized Recommendations and othe features to help you discover programs you'll love, and enjoy more of what you want, when you want it.

This guide has important tips to help you the most out of the advanced features of your Now TV set top box.

If you have not vet subscribed to Now TV, please call us at 2888 0008 (press 2) to sign up.

First Time Activation Code:

Enter the first 4 digits of your Hong Kong ID/passport number


Please key in your activation code on screen to start your Now TV service.

4 0000 " is the default PIN Number

This PIN can be used to subscribe to Now TV pay TV channels and certain other services as well as activate the Parental Control Lock on selected channels and program categories. Please do not disclose your PIN to prevent any unauthorized use. You are advised to change your PIN regularly for added security. Select HOME > Settings 🌣 > Change PIN

*Note: Subscription to Now TV service is subject to the Terms and Conditions of Now TV. Now TV service is provided by Now TV Limited and / or its affiliates in accordance with the Terms and Conditions of Now TV. For further details on the Terms and Conditions of Now TV, please refer to Now TV website (www.nowtv.now.com/terms-and-conditions) or access through TV select "Settings" and choose "Terms and Conditions".


The all new TV Guide makes channe



saved to view after their air-date. Use the "+" button to add the show to your Watchlist.

Starred programs are

Set Favorite Highlight the channel logo at left, then Subscribed or channels by genre. use the color button to mark as a favorite.



MY NOW

Personal Recommendations

Most Recent Pick up where you last left off.

channels previously watched. You may choose to turn off the History function in Settings.)

WATCHLIST


Get introduced to content selected just for you.



The Watchlist helps you keep track of your favorite programs and shows, Use the '+' button or on screen selection to add programs to your list, Many TV shows and future episodes will be saved for you to watch later,


Unfortunately, some channel operators don't allow users to save their TV programs. For those shows, however, the Watchlist will still help you find other times to watch an upcoming episodes easily.

Remote Control



*Available to customers having subscribed TV Recording Combo Service

Watch movies and shows when



Video Express




You can also enjoy the very latest blockbusters on a pay-per-view basis. Get 48-hour unlimited viewing with Video Express using either

WHILE WATCHING TV CHANNELS

These functions are available while watching television channels:







channel's program line-up. Select a show to see more info.



Watchlist at the bottom of the screen.




Jse the back button to show your History Switch quickly between your most recen channels and shows. Char watched them for a few minutes.





When you want - Where you want! Free!

Enjoy more of your favorites on demand, anvtime. anywhere, Control your set top box and Screen Cast from your phone or tablet. It's free!





Digital Terrestrial Television (DTT)

Your set top box includes a DTT tuner allowing you to enjoy digital terrestrial TV without switching sources or remote controls,

Select **HOME** > **SETTINGS** \Longrightarrow > DTT Channel Tuning and follow the on screen instruction to auto-tune. Once set-up, simply enter the DTT channel numbers to access DTT channels.

Video Background Setting

For customers with Fiber-to-the-Home broadband service. Now TV allows vou to browse menus without leaving your television program. To adjust the brightness of the background video. Select HOME > SETTINGS 🖎 > Video & Audio Settings > Background video.

Settings content

- Billing Inquiry
- Update to HD
- · Channel Management
- Now ID Now Dollars
- Now Player Mobile App
- Parental Lock
- Change PIN
- 中文 (Language Option)

DTT Channel Tuning

Remote Control Settings

- TV Recording & Control Live TV
- Match Alert Message Settings
- History Settings
- Video & Audio Settings
- · Mini Guide Settings Netflix Info
- Video Tutorials
- Classifications
 - Terms & Conditions

Connection Diagram

RFOUT RF IN AVOUT AUDIO OUT HDMI OUT SV 1A SV 1A STHERMET

Ethernet Cable(not provided

Power Adapter

GX-PC4312H

Specification

Net Weight: 578 g

- Dimensions: 225 (W) x 33 (H) x 170 (D) mm Operating Temperature Range: 0 °C to 45 °C
- Operating Humidity Range: 0 % to 90 %

DTMB

Input Connector Type

Female connector follow IEC 60169-2

Broadcasting Rx Frequency

■ 470 ~ 862 MHz

#1 x mini AV

Broadcasting Rx Level

-10 dBm ~ -82 dBm Analog Audio/Video Output port

Dolby Digital Plus

Ethernet port

Internal WiFi

■ 10/100/1000 Mbit

BLE operation)

Power Supply

Video Codec

H 265/HEVC

Audio Codec

MPEG I laver 1/2/3

/ideo Resolution

Micro SD memory

Up to 128GB

A Samsung mini AV cable is required to connect analog AV output port to TV composite input.

CVBS (576i)

External PSU (14 V / 2.5 A)

MPEG2 (MP@ML, LL, HL)

MPEG4 AVC H.264 (MP@L4, HP@L4)

HDMI (576i/576p/720p/1080i/1080p/2160p)

802.11ac 2x2 dual band (non-concurrent),

4.1 supporting dual mode low energy(BT and

Digital Audio/Video Output port

- Audio/Video: 1 x HDMI 2.0 Audio: 1 x SPDIF(optical)

USB port

1 x USB 3.0 (1A)

- 1 x USB 2.0 (1A)

Design and specifications are subject to change without prior notice.

Weight and dimensions are approximate.

Trouble Shooting Table Problem Encountered/ What can you do?

Error Code

Black screen/80061B	Step 1: Switch off the modem and set top box Step 2: Reconnect the broadband cable into the square socket of the modem Step 3: Unplug the power cord from the modem Step 4: Re-plug the modem power in 15 seconds; and wait for the lights to turn on. (around 2 – 3 minutes) Step 5: Reboot the set top box by pressing the Power button located on the top of your set top box for 5 seconds
Frozen screen/80062A-H	Step 1: Switch off the modem and set top box Step 2: Switch on modem 15 seconds later; and wait for LED signal to become stable (around 2-3 minutes) Step 3: Restart the set top box
80061A	Step 1: Ensure your modem is switched on and the cable from moder to set top box is properly connected Step 2: Reboot your set top box by pressing the Power button located on the top of your set top box for 5 seconds
80063	Step 1: Reboot your set top box by pressing the Power button located on the top of your set top box for 5 seconds





in HOME > Settings 🌣 > Video Tutorials!

customer's HKID/Passport number)

Step 2: Enter your service activation code. (First 4 digits of Registered

"If you have any enquiries regarding the service", please call Now TV Customer Service Hotline (\infty 1833 888 or email us at (\infty cs@nowtv.now.com for assistance.

PCCW Customer Service has launched a brand new Facebook page! Visit www.facebook.com/pccwcs, simply click 1 "Like" to become our fan and enjoy the convenience of a one-stop direct-response PCCW customer service.

License Information and Notice

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, Pro Logic, and the double-D symbol are trademarks of Dolby Laboratories.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks

or registered trademarks of HDMI Licensing LLC in the United States and other countries. Samsung Open Source License

To send inquiries and requests for questions regarding open sources, contact Samsung via

You may also find a copy of the source at http://opensource.samsung.com/ Open Source License Notice is written only English.

now one now and Now TV are trade marks of PCCW.

*Pictures for reference only.

For FAQ details, please refer to our website: www.nowtv.now.com.

All content is subject to change without prior notice. Please refer to nowty now com for the most updated user guide.

STB NowOne ©2024 Now TV Limited















